



- ★ Parete prefabbricata di spessore variabile
- P Profilo elastico di tenuta a cavità isolanti
- PT Interruzione ponte termico
- TI Soglia angolare in alluminio
- GP Guida posteriore in alluminio anodizzato
- PS Pulegge di scorrimento
- CBA Copribinario in alluminio anodizzato
- COP Controporta in alluminio per bloccaggio alla parete

(FP) Soglia a filo pavimento

(SS) Senza soglia



- ★ Paroi prefabriquée
- P Joint en caoutchouc élastique
- PT Interruption pont thermique
- TI Seuil en aluminium
- GP Guide postérieure en aluminium anodisé
- PS Puelles de roulement
- CBA Cache-rail en aluminium anodisé
- COP Contre-cadre en aluminium anodisé

(FP) Seuil à fil sol

(SS) Sans seuil



- ★ Prefabricated panel
- P Elastic rubber strip
- PT Thermic cut
- TI Threshold
- GP Rear runner in aluminium profile
- PS Sliding wheels
- CBA Aluminium track cover
- COP Counter-frame in aluminium profile

(FP) Threshold for same level floor

(SS) Without threshold

Per installare la porta occorre un foro nella parete di:

**L + 100 mm
H + 50 mm**

Pour monter la porte il faut faire un trou dans la paroi de:

**L + 100 mm
H + 50 mm**

To place the door into the wall make an hole:

**L + 100 mm
H + 50 mm**